



NOTE: USE ALT RS233 MORTAR AS NEEDED TO FILL ALLIGATORING, MINOR FISSURES & LEVEL ROOF BIRD-BATHS OR DEPRESSIONS.



**ALT R230 MEMBRANE ROOF ASSEMBLY
BUR RECOVERY (NON-INSULATED)**

REVISION	ISSUE DATE	SCALE	DRAWN BY
0	1-15-2010	N.T.S.	D.R.W.

DRAWING NO.:
R-9
AR_09