

# ALT R230 Membrane BUR Roof Recovery Specification (non-insulated)



## Technical Data Sheet

### PART 1 GENERAL

<b>System:</b>	New cold liquid-applied reinforced roof membrane and optional light roof traffic surfacing system, including all other ancillary roof work but not limited to installation of roof drain, penetration and perimeter flashings, sealants and metal work as specified. This specification is recommended for roofing applications with limited access. For projects intended with regular roof traffic, see <i>ALT R230 Membrane Roofing &amp; Walk-able Surfacing</i> specification.
<b>Weather Restrictions:</b>	Do not apply membrane during or with the threat of inclement weather. Application of cold liquid-applied reinforced membrane may proceed while air temperature is between 32° F (0° C) and 95° F (35° C) for ALT primers and finish or 23° F (-5° C) and 95° F (35° C) for ALT R230 membrane, providing the substrate is a minimum of 5 degrees above the dew point temperature, clean and dry.
<b>Roofing Warranty:</b>	Manufacturer's Warranty: Provide 20-year standard manufacturer's warranty under provisions of this section.

### PART 2 PRODUCTS

<b>Membrane:</b>	Cold liquid-applied reinforced membrane with non-woven reinforcing fabric, for a finished dry film membrane thickness of .080 inch nominal per ply; slip-resistant aggregate and colored topcoat finish as selected by owner from manufacturer's standard palette of colors; conforming to ASTM C 836. Subject to compliance with requirements, provide ALT R230 resin for use in an adhered membrane waterproofing and surfacing system.
<b>Flashing:</b>	Cold liquid-applied membrane with a non-woven reinforcing fabric, for a finished dry film membrane thickness of .080 inch nominal per ply; integral color finish as selected by owner from manufacturer's standard palette of colors; conforming to ASTM C 836. Subject to compliance with requirements, provide ALT R230 Thixo resin for use in an adhered flashing membrane system.
<b>Accessories:</b>	Provide resin primers, additives, surfacing topcoats, and accessory products as required or recommended by the Membrane Manufacturer.
<b>Base Sheet: (Optional)</b>	APP granulated cap sheet, SBS granulated cap sheet, SBS heavy base sheet; applied over BUR substrate when required prior to application of the liquid-applied roofing membrane.

### PART 3 EXECUTION

<b>Preparation:</b>	<p>All substrates must be free from gross irregularities, loose, unsound or foreign material such as dirt, ice, snow, water, grease, oil, release agents, lacquers, or any other condition that would be detrimental to adhesion of the primer and/or resin to the substrate. Some flashing surfaces may require scarifying, sandblasting or grinding to achieve a suitable substrate.</p> <p>Substrate shall have maximum moisture content of six (6) percent or 75% relative humidity, and be prepared as required to provide adhesion of the membrane to substrate with minimum bond strength of 116 psi (0.8 N/mm<sup>2</sup>) for roofing applications. Determinations of bond strength and moisture content shall be performed periodically by the Contractor throughout the course of work.</p> <p>On gravel surfaced roofs, all loose gravel shall be removed by spudding and power vacuuming. Gravel shall be removed to and disposed of off-site in a legal manner at an appropriate facility.</p> <p>For all roofs, blisters and ridges must be cut and patched using roofing manufacturer's resin-mortar patching mix to provide a reasonably level substrate surface.</p> <p>Strip and remove all existing roof membrane and roof perimeter, base, curb, pipe, drain and penetration flashings. Prepare roof and flashing substrate as required for application of new cold liquid-applied membrane.</p>
---------------------	---

<p><b>Leveling &amp; Repair:</b></p>	<p>Level, plane and smooth previously gravel surfaced (gravel removed) or alligatored smooth surface asphaltic built-up roofs using Membrane Manufacturers appropriate proprietary resin mortar. ALT RS233 Mortar should be placed after priming substrate with Membrane Manufacturers proprietary primer, and in lifts no greater than the maximum thicknesses indicated by the Membrane Manufacturer.</p> <p>Mix ALT RS233 Mortar with 0.7 - 1.2mm quartz aggregate as a filler/extender at a 1:0.75 ratio resin to sand by weight. Using a flat trowel or squeegee, apply an even layer of ALT RS233 Mortar at minimum consumption of 0.37 kg/sf (4.0 kg/m<sup>2</sup>). Work wet resin with a pin rake or spiked roller, removing trapped air, and smoothing as required.</p> <p>Curing: ALT RS233 Mortar is rainproof after approximately 30-minutes, and should be allowed a cure time of approximate 1-hour before walked-on or application of the next layer.</p>
<p><b>Patching:</b></p>	<p>For patching and repairs, fill cavities with ALT R290 Paste or ALT RS242 Mortar and trowel to achieve a flat surface. ALT resin-mortars are recommended for trowel applied repairs with or without added quartz aggregate filler. Mix and apply all resin mortars in strict accordance with written instructions of Membrane Manufacturer.</p>
<p><b>Base Sheet: (Optional)</b></p>	<p>In lieu of leveling, patching and repair per the above, when acceptable install base sheet in accordance with base sheet manufacturer's current published specifications and recommendations for use as a substrate for a cold liquid-applied membrane. Base sheet may be attached using mechanical fasteners, hot asphalt adhesive, or torch applied.</p> <p>Overlap Joints: Overlap side laps a minimum of 2" and end laps a minimum of 4", or as recommended by the base sheet manufacturer. All joints and overlaps are to be heat-sealed before end of each day's work.</p>
<p><b>Primer:</b></p>	<p>Prime all substrates as recommended or required by Membrane Manufacturer. Primer is required on asphalt, concrete, wood and metals. For other substrates, contact the Membrane Manufacturer for recommendations.</p> <p><u>Asphalt/Concrete/Wood:</u> Apply two-component ALT Primer with a lambswool roller. Minimum consumption: 0.037 kg/sf (0.4 kg/m<sup>2</sup>) Cure Time: Minimum of 45 minutes.</p> <p><i>*Note: Consumption and yield of primer will vary depending upon smoothness and absorbency of the substrate.</i></p>
<p><b>Flashing:</b></p>	<p>Apply an even base layer of ALT R230 Thixo resin, work ALT Fleece reinforcement into the wet resin saturating from the bottom up removing trapped air using a lambswool roller. Apply supplemental ALT R230 resin directly over the fleece as required to complete saturation and allow to cure until solid.</p> <p>Base Coat: Minimum consumption of 0.19 kg/sf (2.0 kg/m<sup>2</sup>) Top Coat: Minimum consumption of 0.12 kg/sf (1.3 kg/m<sup>2</sup>)</p> <p>Laps/Seams: Maintain a minimum 2-inch (5 cm) overlap at all side laps of adjacent fleece rows and 4-inch (10 cm) overlaps at butt laps, tie-ins and flashings (reinforcing and resin).</p> <p>Curing: ALT R230 membrane is rainproof after approximately 30-minutes, and can be walked-on or top coated with aesthetic and/or skid resistant surface topcoat in approximately 45-minutes.</p>

<p><b>Main Deck Roof Membrane:</b></p>	<p>Apply an even base layer of ALT R230 resin, work ALT Fleece reinforcement into the wet resin saturating from the bottom up removing trapped air using a lambswool roller. Apply supplemental ALT R230 resin directly over the fleece as required to complete saturation and allow to cure until solid.</p> <p>Base Coat: Minimum consumption of 0.19 kg/sf (2.0 kg/m<sup>2</sup>) Top Coat: Minimum consumption of 0.12 kg/sf (1.3 kg/m<sup>2</sup>)</p> <p>Laps/Seams: Maintain a minimum 2-inch (5 cm) overlap at all side laps of adjacent fleece rows and 4-inch (10 cm) overlaps at butt laps, tie-ins and flashings (reinforcing and resin).</p> <p>Curing: ALT R230 membrane is rainproof after approximately 30-minutes, and can be walked-on or top coated with aesthetic and/or skid resistant surface topcoat in approximately 45-minutes.</p>
<p><b>Anti-Slip Aesthetic Finish:</b></p>	<p>This finish option provides for the use of medium grain aggregates to create an aesthetic slip-resistant wearing surface. A combination of colored aggregates or a pigmented finish may be used to create a variety of aesthetic treatments.</p> <p><u>Aggregate Bedding Layer:</u> Apply an even layer of ALT Finish 288, or ALT Finish 220 Clear when using color quartz aggregates, using the lambswool roller. Broadcast aggregate into the wet resin to excess for full coverage.</p> <p>Bedding Coat: Minimum consumption of 0.056 kg/sf (0.6 kg/m<sup>2</sup>) Aggregate: Approximate consumption of 0.46 kg/sf (5.0 kg/m<sup>2</sup>) or 1.0 lbs/sf</p> <p>Aggregate Sizes: Colored Quartz: 0.3 – 0.8mm (Note: Use ALT Finish 220 Clear) Crystal Quartz: 0.4 – 0.8mm</p> <p>Curing: ALT Finish is rainproof after approximately 30-minutes, and can be walked-on in approximately 2-hours. ALT Finish should be applied within 24-hours of the membrane application.</p> <p><u>Finish Seal-Coat:</u> Apply proprietary aesthetic surface finish and seal coat. Apply an even application of ALT Finish 288 pigmented resin, or ALT Finish 220 Clear when using color quartz aggregate, using a hard rubber squeegee and a lambswool roller. Minimum consumption: 0.046 kg/sf (0.50 kg/m<sup>2</sup>).</p> <p>Curing: ALT Finish is rainproof after approximately 30-minutes, and can be walked-on in approximately 2-hours. ALT Finish should be applied within 24-hours of the membrane application. If the finished is applied any time after this, the top layer of the membrane must be cleaned with ALT Activator.</p>
<p><b>Aesthetic Color Finish:</b></p>	<p>This finish option provides for the use of pigmented finish to create a variety of aesthetic treatments.</p> <p><u>Color Finish Topcoat:</u> Apply proprietary aesthetic surface finish topcoat. Apply an even application of ALT Finish 288 pigmented resin using a hard rubber squeegee and a lambswool roller.</p> <p>Minimum consumption: 0.046 kg/sf (0.50 kg/m<sup>2</sup>).</p> <p>Curing: ALT Finish is rainproof after approximately 30-minutes, and can be walked-on in approximately 2-hours. ALT Finish should be applied within 24-hours of the membrane application. If the finished is applied any time after this, the top layer of the membrane must be cleaned with ALT Activator.</p>

<b>Staging:</b>	<p>In a normal ALT R230 membrane application, flashings are installed first, followed by the application of the deck waterproofing, aggregate surfacing and seal-coats.</p> <p>Work Interruptions: If work is interrupted for more than 12-hours, use ALT Activator to reactivate the transition area. ALT Activator should be allowed a minimum of 20-minutes evaporation time after application, and over-coated within 60-minutes of application. Re-apply ALT Activator as required to assure proper reactivation of transition areas.</p> <p>Tie-ins: For all tie-in locations, provide a minimum overlap of 4 inches (10 cm), reinforcing fabric and resin.</p>
<b>Water Testing:</b>	<p>Prior to applying aggregate finish and seal-coat, flood test all horizontal applications with a minimum 2” (51 mm) head of water for 24 hours. Mark any leaks and repair when the membrane is dry. Before flood testing, be sure the structure will withstand the dead load of the water. For well-sloped decks, segment the flood test to avoid deep water near drains.</p> <p>Conduct the flood test after completing the ALT R230 membrane application. Immediately after the flood test and all necessary repairs are made apply surfacing and finish.</p>
<b>Protection:</b>	<p>Upon completion of new work (including all associated work), institute appropriate procedures for surveillance and protection of finished work during remainder of construction period. Protect all areas where membrane has been installed.</p>

#### DISCLAIMER

**NO WARRANTY, EXPRESS OR IMPLIED, IS MADE IN THIS DOCUMENT. THE PRODUCT IS NOT CLAIMED TO BE MERCHANTABLE OR FIT FOR ANY PARTICULAR PURPOSE.** User and certified ALT Global applicators determine suitability only. See individual ALT Global product data sheets, MSDS sheets, guide specifications and details for complete information regarding the suitability, application and handling of ALT Global products.